



PLAN VIEW

<u>NOTES:</u>

- 1. INTERNAL BRACING MAY CHANGE DEPENDING ON TOWER SUPPLIER. 2. ORIENTATION OF INSULATOR $oldsymbol{\Phi}$ In Plan Will Vary from 0°-50°
- FOR EACH TOWER LOCATION. 3. ALL DIMENSIONS IN MILLIMETRES UNLESS STATED OTHERWISE.
- 4. ACTUAL DIMENSIONS MAY BE LESS THAN SHOWN ON DRAWING, DEPENDING ON TOWER SUPPLIER.
- 5. OUTLINE BASED ON EXISTING 400kV STRAIN TOWER (TYPE 408: PE517-D021-019-015).

